

# FTC1-024 Fuel/Timing Calibrator for 1993 VW Golf 2.0L

## Use and Installation Instructions:

- 1) Use with R4 software
- 2) Select Vac/Pressure and Programmable Signal Calibrator under system settings. Refer to the FTC1 data sheet for more information.
- 3) Set for 4-cylinder and 4-stroke under engine settings
- 4) Program the fuel in Map table A
- 5) Use the signal modify connection per wiring below
- 6) A cell value of 10 is neutral. Reduce the cell value to lean the mixture. Increase the cell value to make the mixture richer.
- 7) The highest cell value is 20.
- 8) Cell values can have one decimal place. For example 10.1. There are a total of 200 levels available for cell value
- 9) Program timing retard in Map table B
- 10) The cell values can range from 0 to 20. A value of 20 will result in 20 degrees of retard.
- 11) Cell values can have one decimal place. For example 10.1. There are a total of 200 levels available for cell value
- 12) Disconnect the battery before making connections to the factory wiring harness.
- 13) Use solder and heat shrink for the best electrical connections
- 14) Connect the **RED** wire (B+) to the black wire on ECU pin 38
- 15) Connect the **BLACK** wire (B-) to the brown wire on ECU pin 10
- 16) Connect the **BLACK/YELLOW** wire (tach) to the black/red wire on ECU pin 8
- 17) Cut the red MAF sensor wire leading from the stock MAF sensor to ECU pin 17
- 18) Connect the **GREEN** wire to the side of the cut wire that leads to the MAF sensor
- 19) Connect the **VIOLET** wire to the MAF sensor wire leading to the ECU
- 20) Cut the red crank (+) sensor wire on ECU pin 67
- 21) Connect the **YELLOW** wire to the cut (+) wire leading to the crank sensor
- 22) Connect the **YELLOW/BLACK** wire to the wire leading to the ECU crank (+) sensor input
- 23) Cut the green crank (-) sensor wire on ECU pin 68
- 24) Connect the **GRAY** wire to the cut (-) wire leading to the crank sensor
- 25) Connect the **GRAY/BLACK** wire to the wire leading to the ECU crank (-) sensor input
- 26) Cut the white/red cam sensor wire on ECU pin 44
- 27) Connect the **TAN** wire to the wire leading to the cam sensor
- 28) Connect the **TAN/BLACK** wire to the wire leading to the ECU cam sensor input
- 29) Reconnect the battery