

Turbo Tuner 2 Installation Instructions

1. Put the ECU in Sleep Mode

Before you plug in your Turbo Tuner your ECU must be in sleep mode. To insure that the ECU is in sleep mode do one of the following:

- 1) If the engine is cold, open the hood, close the doors, lock the car and wait 30 seconds
- 2) If the engine is warm, open the hood, close the doors, lock the car and wait 20 minutes
- 3) If the engine is warm and you can't wait 20 minutes, disconnect the battery

2. Find the TMAP Sensor

The TMAP sensor is on the intake tube on the driver side of the engine. Its location is seven inches below the driver side, rear corner of the airbox cover. The TMAP sensor has four wires. Do not confuse the TMAP sensor with the 3-wire MAP sensor that is on top of the intake manifold. The circle in the first photo shows the location of the TMAP sensor. One of the mounting screws for the sensor is visible in the center of the photo. The end of the tape measure in the second photo is touching the TMAP sensor. The third photo shows the arm position to access the TMAP sensor. The fourth photo shows a close-up of the TMAP sensor.

On the 135i and 535i it is easier to access the TMAP sensor if you remove the airbox. See the airbox removal instructions for details on that procedure.



The TMAP sensor is hard to see



It is seven inches below the driver side rear corner of the airbox.



If the connection is done with the airbox in place, you have to work by feel



A clear view of the TMAP sensor.

3. Unplug the TMAP Connector

A USB connector is an ideal tool for releasing the lock on the TMAP connector. It has very thin metal piece that will slide under the connector lock without putting too much strain on the lock. You can also use a guitar pick or small screwdriver. Be careful to not bend up the tap too far or it will break.



A USB connector makes a good removal tool.



The connector separated from the TMAP sensor.



The Turbo Tuner 2 connectors plug in-line between the TMAP sensor and connector.



The internal adjustable boost setting.

4. Plug in the Turbo Tuner

Plug the large connector on the Turbo Tuner into the factory harness connector, then plug the small Turbo Tuner connector into the TMAP sensor.

5. Adjust the Setting

Remove the two screws on the cover. Turn the setting for your desired boost. The zero setting gives stock boost. The 50 setting adds 2 psi and is safe and conservative. The 75 setting is similar to the original Turbo Tuner. The 100 setting adds 4 psi of boost and is for 93 or higher octane fuel only.

6. Secure the Unit

Use the zip tie to secure the unit in an accessible location.



Split Second 1949 E. Deere Ave. Santa Ana, CA 92705 www.splitsec.com